



Halt Tough Grease and Soil for an Exceptional Clean

Concentrated, high sudsing dishwashing detergent for use on pots and pans and all other kitchenware.

SWISHER AURORA HAND DISHWASHING DETERGENT

- Cuts through grease and soil with minimal scrubbing
- Long-lasting suds for long-lasting cleaning
- Tough on grime, gentle on hands



Swisher Aurora Hand Dishwashing Detergent

is a high performance, high sudsing liquid detergent designed to cut through grease and tough food soils.

It includes a powerful combination of surfactants to provide great grease cutting and soil suspension against the toughest baked-on food soils. Long-lasting suds attack heavy food soils, but remain gentle on hands.

DIRECTIONS:

- Sink One:** Fill sink using one ounce of Swisher Aurora Hand Dishwashing Detergent per 10 gallons of hot water (75 °F or higher). Adjust amount of product according to soil loads.
- Sink Two:** Immerse pots and pans in clean water. Remove and let excess water run back into sink.
- Sink Three:** Fill sink with warm water (75–100 °F). Use an appropriate EPA registered Swisher sanitizer for a sanitizing rinse, following directions on label. Let air dry. Do not wipe. Follow local health department regulations for rinsing.



For expert solutions and exceptional results, Swisher is your go-to partner. From foodservice and lodging to long term care, we help create the cleanest and healthiest environments.

Call **1.800.360.SWSH** for more information.

1 Ecolab Place St. Paul, MN 55102

©2017 Ecolab USA Inc. All rights reserved. 51824/0400/0817



MANUAL WAREWASHING SOLUTIONS

PRODUCT	PACK SIZE	SWSH #	DIST #
Swisher Aurora Hand Dishwashing Detergent	6-32 oz	6101415	
	2-1 gal	6101416	
	1-5 gal	6101417	

NOTES:

Refer to your local health regulations for additional guidance on sanitizer use.

