

IMPRESS YOUR GUESTS WITH CLEAN DISHES EVERY VISIT

Solid Dishmachine Detergent

This heavy-duty dishmachine detergent is a consistent, high performer that works efficiently on tough soils, even in hard water.

- High performing dishmachine detergent that creates long lasting guest impression
- Formulated to remove tough soils and reduce redeposition
- Smaller pack reduces packaging waste and maximizes storage space



DIRECTIONS FOR USE:

1. Install a Wash Max Dispenser and adjust it to automatically dispense the proper amount of product.
2. Load Solid Dishmachine Detergent into the dispenser by carefully removing the empty capsule from the dispenser and turn upright to avoid spills.
3. Remove the cap from the new capsule and use the cap to seal the empty capsule immediately.
4. Use the handle to place the full container in the dispenser with the open end facing down.



MACHINE WAREWASHING SOLUTIONS

PRODUCT	PACK SIZE	SWSH #	DIST #
Solid Dishmachine Detergent	2 – 9 lb	6102095	

The Swisher experienced and dedicated sales team provide you personalized support to help you run a clean and safe operation.

Call **1 800 360 SWSH** or visit **SWSH.com** for more information.

1 Ecolab Place St. Paul, MN 55102

©2024 Ecolab USA Inc. All rights reserved. 58736/0401/0224

