



## Remove Baked-On Soils and Carbonized Grease Quickly

Foaming aerosol is ideal for cleaning ovens, barbecue grills and stainless steel equipment.

## SWISHER OVEN AND GRILL CLEANER AEROSOL

- Extend product contact time with the power of clinging foam
- Helps reduce dripping and provides even coverage
- Clean, fresh lemon scent



**Swisher Oven and Grill Cleaner Aerosol**

effectively revitalizes stainless steel food preparation equipment by penetrating carbonized grease and other soils. Use on ovens, grills, stove hoods and other stainless steel surfaces.

**DIRECTIONS:**

1. Wear long-sleeved rubber gloves and protective eyewear.
2. Turn off current in electric ovens and pilot lights on gas ovens.
3. Shake can well before using.
4. Hold can 9–12 inches (23–30 cm) away and spray a generous amount on surface.
5. Allow to set 5–10 minutes on warm surface and 20–30 minutes on cool surface.
6. Wipe the surface clean with paper towel or a clean cloth, then rinse surfaces with potable water to remove remaining cleaner.
5. Repeat process in cases of heavy cooking, using steel wool or soap pad.

**Overnight or Cold Oven Cleaning:**

1. Follow above directions for use in a cold oven. Spray oven surfaces; close oven door.
2. Allow to stand overnight (eight hours or longer). Wipe clean with a wet sponge.



**OVEN AND GRILL CLEANER SOLUTIONS**

PRODUCT	PACK SIZE	SWSH #	DIST #
Swisher Oven and Grill Cleaner Aerosol	6-20 oz	6101313	



For expert solutions and exceptional results, Swisher is your go-to partner. From foodservice and lodging to long term care, we help create the cleanest and healthiest environments.

Call **1.800.360.SWSH** for more information.

